

INTERNAL SERIAL NUMBER

RPN mode is assumed.

1. Attach Library 256 by entering 256 ATTACH

```
DEG NYZ DEC C~ 'X'  
<HOME>  
-----  
6:  
5:  
4:  
3:  
2:  
1:  
256 ATTACH  
IOPAR CASDI
```

2. Enter the command SERIAL and press ENTER

```
DEG NYZ DEC C~ 'X'  
<HOME>  
-----  
6:  
5:  
4:  
3:  
2:  
1:  
SERIAL  
IOPAR CASDI
```

3. Press down arrow and arrow over to the end of the string

```
DEG NYZ DEC C~ 'X' PRG  
-----
```

```
...1 Number: CNA8393146  
SWZ SWZ DEL DEL LINS
```

4. The internal serial number above is: CNA8393146